

## WHISPERLITE OPERATING INSTRUCTIONS


READ, UNDERSTAND, AND FOLLOW ALL instructions and warnings in this manual before using this stove.

### 7

#### PREPARE FUEL BOTTLE

The WhisperLite only burns White Gas. See *Fuel Information*.

- 1. Fill Fuel Bottle to fill line only.**  
Air space is necessary for fuel expansion.
- 2. Insert Pump into Fuel Bottle and firmly tighten.**
- 3. Close the Pump Control Valve, then stroke Plunger (20-30 strokes).**  
Less fuel requires more strokes or pressure.  
Pump until firm resistance is felt.



#### ⚠ WARNING

Use MSR fuel bottles only. Non-MSR fuel bottles may leak fuel, causing fire and injury. Keep children away from stove and fuel. Never leave a burning or hot stove unattended.